Additional Operation Instructions HDDVR202 (Designed to be used in conjunction with instruction manual provided with unit)

- 1. Once the unit is switched on you can switch between recording mode and still image mode. This can be done by pressing the Mode Key (13)
- 2. When in Video Mode press the Menu Key (10). The following menu will appear:



- 3. The menu consists of two pages. To scroll through the list in the menu use the Up Key (11) and Down Key (12).
- 4. To access each item in the menu once highlighted press the Ok/Rec Key (3). This will bring up the options for each menu. To select the option scroll and highlight the one you wish to select and press OK/Rec Key (3) again. Please see below:





5. When each function is turned on the symbol on the menu list will appear on the main screen of the unit. Please see picture below.

(The picture reveals it is in video mode, loop recording is set to 10 minutes, exposure is 0, infra-red LEDS are turned off, g sensor is turned on, beep sound is turned on, recording time is 28 minutes, resolution is 720p, SD card storage and battery has one bar of power left).



6. To access the settings menu, Turn the unit on and press the Menu Key (10) twice. This will allow you to access a settings menu which is 3 pages long. You can navigate this menu through same procedure as above.