

PURE SOUND - COMPONENT SPEAKER 70 m 4/5/5



Thank you for purchasing the component speakers. For the secure installation and perfect operation of your speaker, please read and

you use the apparatus.

understand all instructions before

Product information	NSE 4	NSE 5	NSE 6
Speaker type:	4"(10.0cm) 2-way	5"(12.7cm) 2-way	6.5"(16.5cm) 2-way
Mounting depth(woofer):	>2.0"(52mm)	>1.8"(48mm)	>2.4"(62mm)
RMS power:	15 watts	20 watts	25 watts
Peak music power:	240 watts	260 watts	300 watts
Sensitivity(1W/m):	86 dB	87 dB	88 dB
Frequency response:	125 - 20k Hz	115 - 20k Hz	85 - 20k Hz
Impedance:	4 ohms	4 ohms	4 ohms
Voice coil:	KSV 25.5mm	TSV 25.5mm	TSV 25.5mm
Magnet mass:	6.4 Oz (181.4g)	6.4 Oz (181.4g)	9.8 Oz (277.8g)
Gross mass:	Approx. 1.5 kg	Approx. 1.6 kg	Approx. 2.2 kg

Important

instructions, the warranty does not apply. Read and understand all instructions before you use the apparatus. If damage is caused by failure to follow

Use only the supplied mounting hardware for a safe and secure installation.

Do not continuously use the speaker system beyond the peak power handling capacity.

prevent damage caused by the magnets in the speakers. Keep credit cards, watches, recorded tapes etc. with magnetic coding away from the speaker system to

cleaners on the apparatus. Clean the apparatus with soft, damp cloth. Never use substances such as alcohol, chemicals or household

What's in the box

Check and identify the contents of your package:

Installation manual(x1);
Woofer(x2);
Grille net + Frame(x2);
Network(with wire)(x2);


5. Tweeter (with wire) (x2); 6. Ø4×25mm Screw(x8); 7. Shrapnel (1x8) 8.1.5m wire(x2)

Installation

Option 1: Mount the woofer on door (front or rear)

You can mount the woofers on the front/rear door of your car.

- \star Make sure that nothing obstructs around the mounting location of the door
- \star A hole for mounting may already be cut out of the inner panel of the door(front or rear). In this care, you need to modify the board only.
- \star Ensure that the speaker terminals, frame or magnet do not interfere with any inner parts, such as the window), etc Also ensure that the speaker grille does not touch any inner fittings, such as the window cranks, door handles, arm
- Turn off the car ignition key.
- ★ If the power is on, the click noise generated by the connection may damage the speakers
- Cut out the mounting template from the packing box.
- Paste the template on the location selected for mounting the speaker
- Mark the cut-off hole and the 4 bolt holes. (Fig.1)
- Ġ Cut out the marked area and drill the bolt holes. (Fig.2)
- Remove the grille net. (Fig.3)
- Connect the woofers to the network or car audio
- (See 'How to complete the wiring.')
- Mount on the speaker as shown below. (Fig.4)
- 9 Press and insert the edges of the grille net.
- ★ The speaker grille can be mounted without the grille net, if you like.







Option 2: Mount the woofer on rear tray

You can also mount the speakers into the surface of the rear tray.

Follow the steps in section "Option 1: Mount on door" to mount the speakers into the rear tray.






Mount the Network

- 1. Find a proper location to mount the networks.
- 2. Mount the networks onto the car with the supplied screws.


How to complete the wiring.

your amplifier or car audio directly. Connect the woofers and the tweeters to the 2-way crossover network first, then connect the network to

- ★ Consult the diagram below. Be sure to connect corresponding terminals, i.e. "+" to "+" and "-" to "-". Connection with reversed polarity will degrade the quality of production.
- \star Connect the provided speaker cord to the speaker terminal while holding the lower portion of the speaker terminal



Dimensions (Unit: mm)



[★] Design and specifications are subject to change without notice.